




Canon EOS Rebel T1i Rubber Grip Replacement

If the rubber grip on the camera is dirty or has fallen off, follow these instructions to remove the grip.

Written By: Jonathan Lin





TOOLS:


- [Pry Bar](#) (1)



PARTS:

- [Canon T1i Rubber Grip](#) (1)

Step 1 — Rubber Grip



- Use the plastic opening tool to peel up one side of the rubber grip.
- Gently remove the grip by pulling off the sticky side all the way.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 06:51:21 PM.